770-252-4200 CARDINAL GATES HEARTH GUARD www.cardinalgates.com **INSTALLATION INSTRUCTIONS** Tools you will need to install this child safety device. e **HEARTH GUARD COMES PREASSEMBLED!** EXTEND HEARTH GUARD TO FIT YOUR HEARTH. TURN HEARTH GUARD UPSIDE DOWN. Place on your hearth and adjust by extending Remove packing masking tape from end of adjustment guard to the right to an approximate fit. rod. Max width is 78" A ADD HEARTH SIDE EXTENSIONS. REMOVE PROTECTIVE STRIPS FROM BOTH The two (2) L brackets will slide into open INSIDES OF HEARTH GUARD (A). Set these aside they will be reused. ends through frame clips. Do this on each side of the Hearth Guard. (A) PLACE ON HEARTH AND ADJUST SIDE EXTENSIONS TO YOUR HEARTH DEPTH. REMOVE HEARTH GUARD. UNDERNEATH 6 PLACE HOOK END OF ADJUSTMENT ROD (*) When depth is correct, replace the protective IN NEAREST HOLE - Hearth Guard will need strips from **STEP 3** making sure to overlap the L brackets inserted. This will help hold it in place to be slightly longer than the fireplace hearth. when installed. **(*)** 0000004 CUT EXTRA FOAM PIECES TO FIT IN OPEN GAPS. USING YOUR PHILLIPS HEAD 8 SCREWDRIVER, TIGHTEN HEARTH GUARD ONTO HEARTH. Find exposed tightening NOTE: The two (2) smaller pieces are for the extension back ends. Remove double-back adhesive backing (white) and screw on corner of Hearth Guard. secure onto exposed medal. é.